

VACUUM LOCKS

Using (2) #775 relays.

Unit MUST be programmed for 3.5 second DOORLOCK pulse.

The DOORLOCK wires will be a BLUE or a GREEN, cut this wire in half, then connect to the #775 relays as shown.

