
5-Wire Trunk Release Diagram:


If your Unit has a (-) NEGATIVE Trunk Pop Output, use this diagram...

Connect the WHITE and the YELLOW wire from the #775 relay to 12 volts CONSTANT fused at 10amps.



wire from TRUNK RELEASE switch in vehicle.

Using a (+) POSITIVE Trunk Pop Output:



wire from TRUNK RELEASE switch in vehicle.